

METALpro Wheel Kit Installation Instructions

1. Safely elevate your machine so that the legs are 3 inches off the ground.
2. Slide wheel kits over the legs, so that the bracket is seated against the leg upright as shown in picture.
3. Tighten the two 5/16" bolts on the side of the bracket to secure wheel kit to your machine's leg.
4. Repeat step 2 and 3 for each leg of your machine.
5. Once all legs have been equipped with the wheel kit, slowly lower your machine down so that the machine is fully sitting on the wheels.

***METALpro** is not liable for foul play or damages of your machine or other equipment/persons while using the wheel kit. Wheel kits are designed for use on clean, smooth, and level concrete surfaces. **DO NOT OPERATE MACHINE WITH WHEEL KIT NOT IN THE LOCKED POSITION.** Make sure the area is clear of debris before attempting to move machine.

